Manufacturer	Alfa Romeo	Model	146	Year
Wire	Wire Color	Polarity	Location	
12V	Red	+	Battery or Steering Column	
Starter	red/black		ignition switch	
Ignition	Orange	+	Steering Column	
Power Lock	lt. blue	-	gry CDL module at fusebox	
Power Unlock	white	-	gry CDL module at fusebox	
			Behind Fuse Box Located within a 12 pin	
Parking Lights +	blue & blue/black		connector marked C.	
Parking Lights -				
Hazard Lights				
			Hazard lights relay or Connectors of the	
			steering column	
			Parallel with original door contact or behind	
Door Contact	white/black	-	fuse box	
Trunk Pin	grey/black		Connect to existing contact breaker switch.	
Trunk/Hatch Release	е			